Trusted. Tested. Tough.®

Product information presented here reflects conditions at time of publication. Consult factory regarding discrepancies or inconsistencies.



MAIL TO: P.O. BOX 16347 • Louisville, KY 40256-0347 SHIP TO: 3649 Cane Run Road • Louisville, KY 40211-1961 TEL: (502) 778-2731 • 1 (800) 928-PUMP • FAX: (502) 774-3624 CL0053 0222 Supersedes 1215


SECTION: C3.10.150

Visit our website: zoellerpumps.com

Fusion[®] Series Treatment Systems

PROCESS DESCRIPTION How the Fusion® system works





1. Sedimentation Chamber

This chamber is designed to physically separate solids (sludge) and fat/grease (scum) from the incoming water.

2. Anaerobic Chamber

This chamber contains a spherical-skeleton type of filter media (4.3 inch diameter). Through fixed film processes on the surface of the filter media, biological anaerobic treatment thrives while suspended solids are captured. Furthermore, the microorganisms in this chamber convert nitrates in the recirculated water returning from the aerobic chamber to gaseous nitrogen. The nitrogen then escapes to the atmosphere.

3. Aerobic Filter Media Chamber

The aerobic floating and circulating filter media chamber consists of an aeration upper section and a filter media lower section. The chamber is filled with hollow, cylindrical filter media (0.6 inch diameter and 0.55 inches long). Biological treatment takes place with the help of the fixed film growth on the filter media surface. Aeration is continuous. Residual suspended solids are captured by the filter media circulating in this section. The filter media in the Aeration chamber are backwashed regularly (5 or 10 minute cycle, twice a day) by the backwash system located at the bottom of the chamber. The backwashed water is transferred by an air lift pump back into the sedimentation chamber for further digestion.

4. Treated Water Storage Chamber

During normal operation, a recirculation line transfers a portion of the treated water back into the sedimentation chamber by way of an air lift pump. This chamber is designed to temporarily store treated water coming out of the aerobic filter media chamber. The treated water in the storage chamber is ready for discharge.

All Zoeller Pump Company products must be installed and maintained in accordance with all applicable codes. Product information presented here reflects conditions at time of publication. Consult factory regarding discrepancies or inconsistencies.